

# RAPID CERAMIC TIRE COAT & PROTECTANT

## APPLICATION INSTRUCTIONS

### IMPORTANT - READ ALL INSTRUCTIONS BEFORE STARTING



WE STRONGLY RECOMMEND WATCHING THE INSTRUCTIONAL VIDEO, WHICH SHOWS THIS PROCESS VISUALLY.

Scan QR code or visit:  
[cerakoteceramics.com/tire-instructions](http://cerakoteceramics.com/tire-instructions)

### PREPARATION

- Thoroughly wash your tires with your preferred car wash soap, and let the tires dry completely.
- Shake bottle for 1 minute to ensure the coating is properly mixed prior to application. Attach the included spray nozzle to the bottle of Cerakote Rapid Ceramic Tire Coat.

### RAPID CERAMIC TIRE COAT APPLICATION

- Spray Cerakote Rapid Ceramic Tire Coat liberally onto the surface of the applicator.
- Coat only one tire at a time. Spread the coating evenly over the surface of the tire using long strokes. Pay extra attention to areas of the tire that have grooves, indentations, or protrusions.
- Using a clean microfiber cloth, immediately wipe away any excess coating or over-spray from areas outside of the tire surface.
- Repeat the process for all remaining tires.

### IMPORTANT!

Allow the coating to cure for two hours before exposing to moisture. Wait 24 hours before washing tires.

**LOVE IT?** LET US KNOW BY POSTING YOUR REVIEW  
& PHOTOS TO INSTAGRAM **#CERAKOTEAUTOMOTIVE**



We're here to help. Give us a call at **866.774.7628** or email us at [technicalsupport@cerakoteceramics.com](mailto:technicalsupport@cerakoteceramics.com)