

CERAMIC TRIM COAT

APPLICATION INSTRUCTIONS

IMPORTANT

THIS IS A PERMANENT PRODUCT. FOLLOW ALL INSTRUCTIONS!



TAKE A "BEFORE" PHOTO OF YOUR TRIM

1. Wash and dry surface thoroughly, using a non-wax containing detergent such as blue Dawn® dish soap.
2. **IMPORTANT:** Must be applied to a completely dry surface.
3. **TIP:** Open and close doors, trunk and hood several times to free any trapped water. Roll down windows to avoid any contact with glass. If product comes in contact with paint or glass, remove immediately with a clean dry cloth.
4. Wearing provided gloves, open one (1) pack and wipe trim surface in overlapping passes to ensure full coverage.
5. Rotate wipe as needed, ensuring you use all the surfaces of the wipe. Move to a new pack when wipe becomes dry or soiled.
6. After application, allow a minimum of 1 hour before driving or exposure to moisture.



TAKE AN "AFTER" PHOTO OF YOUR TRIM



SUBMIT YOUR "BEFORE & AFTER" PHOTOS
TO INSTAGRAM #CERAKOTEAUTOMOTIVE

**ALWAYS WEAR CHEMICAL RESISTANT
GLOVES WHILE HANDLING.**



Application Videos and Tips:
[CerakoteCeramics.com](https://cerakoteceramics.com)

Call for help or questions:
866.774.7628

DANGER: Keep out of reach of children. Eye & skin irritant, flammable liquid & harmful vapor. **Read all cautions and instructions prior to use.** For complete SDS and guarantee details visit cerakoteceramics.com

CERAMIC TRIM COAT

APPLICATION INSTRUCTIONS

IMPORTANT

**THIS IS A PERMANENT
PRODUCT. PLEASE FOLLOW
ALL INSTRUCTIONS!**

**ALWAYS WEAR CHEMICAL RESISTANT
GLOVES WHILE HANDLING.**

**SCAN FOR
INSTRUCTIONAL VIDEO**



CERAKOTE®
CERAMIC COATINGS