# RAPID CERAMIC TIRE SHINE APPLICATION INSTRUCTIONS

WE STRONGLY RECOMMEND WATCHING THE INSTRUCTIONAL VIDEO, WHICH SHOWS THIS PROCESS VISUALLY

SCAN WITH YOUR PHONE FOR A HELPFUL INSTRUCTIONAL VIDEO







cerakoteceramics.com/tire-shine-instructions



We're here to help. Give us a call at **866.774.7628** or email us at technical support@cerakoteceramics.com

# IMPORTANT

## READ ALL INSTRUCTIONS BEFORE STARTING



TAKE A "BEFORE" PHOTO OF YOUR TIRES

### PREPARING THE SURFACE

- Thoroughly wash your tires with your preferred car wash soap, and let the tires dry completely.
- Shake bottle for 1 minute to ensure the coating is properly mixed prior to application. Attach the included spray nozzle to the bottle of Cerakote Rapid Ceramic Tire Shine.

### Note:

There is enough coating in this bottle to complete multiple vehicles.

### RAPID CERAMIC TIRE SHINE APPLICATION

- Coating 1 tire at a time, spray Cerakote Rapid Ceramic Tire Shine liberally on your tire to ensure that all surfaces are coated.
- Using the applicator sponge included in the kit, work the coating evenly and completely over the surface of the tire. Pay extra attention to areas of the tire that have grooves, indentations, or protrusions.
- Using a clean microfiber towel, immediately wipe away any excess coating or over-spray from areas that you do not intend
- Repeat the same processes for all remaining tires.
- Allow the coating to fully cure for two hours before exposing to moisture. Wait 24 hours before washing your tires.

Congratulations!
You have achieved maximum gloss & shine!



TAKE AN "AFTER" PHOTO OF YOUR TIRES

MEET THE FAMILY OF CERAKOTE CERAMIC PRODUCTS WWW.CFRAKNTFCFRAMICS.CNM



